

# Default username and password for Netgear FVS336Gv3

Manufacturer/Vendor                      **Netgear**  
Product(s)                                    **FVS336Gv3**



## Summary

---

This article will assist a technician or end user with accessing the administrative configurations using the default username and password of the Netgear FVS336Gv3 device.

## Details

---

### Prerequisites

- User must be connected to the LAN side of the Netgear FVS336Gv3 device.

### Solution

1. Default IP address: **http://192.168.0.1**
2. Default username: **admin**
3. Default password: **password**

## Article properties

---

KB Article ID:                                00155  
KB Article Permalink:  
Category:                                      [Netgear](#)  
Published:                                      Thu, Nov 3, 2016 at 12:40 PM  
Updated:                                        Thu, Nov 3, 2016 at 12:40 PM  
This article has been viewed 443 times.

---